




Assembly Instructions for VisionMount™ LCD Wall Mount Model: VMF

Thank you for choosing Sanus Systems wall mount furniture. This product is designed to mount VESA 75/100 LCD televisions up to 50 pounds onto a vertical wall. It allows you to effortlessly tilt your new television up to 15° up or down without the use of tools. Check carefully to make sure there are no missing or defective parts. Never use defective parts. Improper installation may cause damage or serious injury. If you do not understand these directions, or have any doubts about the safety of the installation, please call a qualified contractor or contact Sanus at 800.359.5520 or www.sanus.com. We can quickly assist you with installation questions and missing or damaged parts. Replacement parts for Sanus products purchased through authorized dealers will be shipped directly to you.

Note: The hardware provided is for wood stud walls only. If you are uncertain about the nature of your installation please consult an expert.

Required Tools: Drill with 3/16" bit, Phillips screw driver

Supplied Parts:



Mounting the Wall Plate: The Wall Plate (a) **MUST be mounted to a wood stud**. Use a high quality stud sensor to locate a stud. It is a good idea to verify where the stud is located with an awl or thin nail. Use the Wall Plate as a template to mark the two hole locations on the wall. Make sure these holes are aligned vertically and centered over the stud. Pre-drill the two holes using a 3/16" drill bit. Attach the Wall Plate to the wall using the two Wall Mount Screws (g) as shown in diagrams 1 and 2. Tighten the Wall Mount Screws until they are just loose enough that you can lift the Wall Plate up and off the wall. Remove the bracket from the wall to attach it to the television.

Diagram 1






Diagram 2



Attaching the Monitor Plate: Mount the assembly to the back of your LCD television using the proper bolts as shown in diagram 3. Place 4 bolts through the TV Mount Plate (b) and tighten snugly into the VESA bolt mounting pattern on the back of the television. M4 (h) and M5 (i) are provided, other sizes are available at your local hardware store.

Diagram 3



Final Assembly: Next hang the assembly over the Wall Mount Screws (g) as shown in diagram 4. Once the bracket slides down over the Wall Mount Screws, tighten them the rest of the way with the Allen Key (j).

Diagram 4

